



A reed switch is released by a magnet. The switch outputs a signal to begin the next transfer.

"Participants must detach and remove a magnet from the device; this action of detaching the magnet must begin the chain of events due to the removal of the magnetic force."



STARTING ACTION

TITLE: WMHS MIT Invitational Circuit Board



Document Number:

REV:

Date: 1/21/2018 11:51 PM






Sheet: 1/16

Diagram showing the wiring for S202. The S202 component has three pins. The top pin is connected to COIN_OUT/16. The middle pin is connected to COIN_VCC. The bottom pin is connected to COIN_OUT_SWITCH.



An incandescent bulb is turned on by the previous transfer and turned off by the output of the transfer. The microcontroller turns on the output when the photocell resistance drops a certain amount.

"Use an exothermic action that produces light to activate a photocell and begins the next action."



EXOTHERMIC ACTION


TITLE: WMHS MIT Invitational Circuit Board

Document Number:

REV:

Date: 1/21/2018 11:51 PM







Sheet: 3/16



An LED is turned on by the previous action. The LED makes the phototransistor change its resistance, signaling the microcontroller to proceed to the next action. The output signal turns the LED off again.

"Use light to initiate a chemical reaction to begin the next action."

CLARIFICATION:
"Use light to initiate the next action."



LIGHT TRIGGERED ACTION


TITLE: WMHS MIT Invitational Circuit Board

Document Number:

REV:






Date: 1/21/2018 11:51 PM

Sheet: 4/16



A solenoid valve is opened, releasing water into a test tube containing ammonium nitrate powder. The powder dissolves in an endothermic reaction, causing the resistance of a thermistor to change.

"Use an endothermic action that begins the next action as a result of the reduction in temperature."



ENDOTHERMIC ACTION



TITLE: WMHS MIT Invitational Circuit Board

Document Number:

REV:

Date: 1/21/2018 11:51 PM

Sheet: 5/16




"Add water to a closed container so that it completes an electric circuit and begins the next action."


TITLE:	WMHS MIT Invitational Circuit Board
--------	-------------------------------------

REV:










Sheet: 6/16



An IR diode receives the LED pulses, which are then decoded by the microcontroller.



An LED connected to the first microcontroller pulses out a certain sequence of pulses.



IR ACTION

TITLE: WMHS MIT Invitational Circuit Board

Document Number:


REV:

Date: 1/21/2018 11:51 PM

Sheet: 7/16




An LED is turned on by the previous action. The LED makes the phototransistor change its resistance, signaling the microcontroller to proceed to the next action. The output signal turns the LED off again.

"Use an infrared beam where the transmitter and receiver are at least 20 cm apart to begin the next action."



A reed switch triggers the next action after it is closed by the electromagnet.

"Activate a student-made electromagnet that begins the next action."



ELECTROMAGNET ACTION


TITLE: WMHS MIT Invitational Circuit Board

Document Number:


REV:

Date: 1/21/2018 11:51 PM

Sheet: 8/16








A solenoid is connected. A mosfet attached to the microcontroller controls it. After a short period of activation, the mosfet is turned off and the solenoid releases.



A normally open limit switch connected here is pressed by the levers., triggering the next action.

A reed switch triggers the next action after it is closed by the electromagnet.

"Use the mechanical advantage of all 3 classes of levers in sequence to begin the next action."



LEVER ACTION


TITLE: WMHS MIT Invitational Circuit Board

Document Number:


REV:

Date: 1/21/2018 11:51 PM


Sheet: 9/16




12V 40W ceramic cartridge heater is connected here. A mosfet attached to the microcontroller controls the heater, turning it on for 9.5 seconds



A set of probes is connected to this header. When salt water from the capillary tube bridges between the electrodes, the next action's microcontroller picks up the change and begins the next action. Bypassed at MIT; instead arduino pro mini was used to read and send signal to next action.



A thermistor connected to J39 provides feedback for the heater cartridge and is used in the PID loop (Incorrectly wired and unused in current device iteration)









An optional 12V brushless fan can be connected to J5 in order to cool the interface between the heater and the device. Used to power external arduino pro mini because of unreliable timer microcontroller at MIT.

A sealed pressure chamber has an open capillary tube extending out of it that is filled with salt water. When a heater inside the pressure vessel turns on, it pushes the salt water out of the capillary tube and onto a pair of electrodes.

"Use a thermal reaction which expands a gas to activate the next action."

CLARIFICATION:

"Use a change in temperature which expands a gas to activate the next action."



GAS EXPANSION ACTION


TITLE: WMHS MIT Invitational Circuit Board

Document Number:


REV:

Date: 1/21/2018 11:51 PM


Sheet: 10/16



A motor connected to this header flips the pressure chamber then pulses back and forth for several seconds to ensure the alkaseltzer is mixing with the water.









A normally open limit switch connected here is pressed by the expanding gas.



A normally open limit switch tells the motor driver when to shut off.

Alkaseltzer and water start uncombined in syringe because of 3D printed "table" inside syringe which holds alkaseltzer up. Syringe flips, combining the two, and plunger slowly moves outwards.

"To receive Bonus Points, participants must designate an action, either scorable or non-scorable, taking over 30 seconds that does not use electricity or springs for power."



CHEMICAL TIMER


TITLE: WMHS MIT Invitational Circuit Board

Document Number:


REV:

Date: 1/21/2018 11:51 PM


Sheet: 11/16









A motor connected to J40 flips the pressure chamber then pulses back and forth to mix the fluids.



A normally open limit switch connected to J7 is pressed by the expanding balloon.



A normally open limit switch tells the motor driver when to shut off.



Syringe with baking soda filled basket attached to plunger is filled with 30% warm vinegar. When syringe is flipped, the two react and the resulting reaction inflates a balloon which hits a limit switch 20cm away.

"Use a chemical reaction that inflates a balloon so that the balloon strikes an object that originally was at least 20 cm away from the balloon, so that the action of striking the object continues the sequence of events."

BALLOON ACTION


TITLE: WMHS MIT Invitational Circuit Board

Document Number:

REV:

Date: 1/21/2018 11:51 PM


Sheet: 12/16



100uF, 25V capacitor was added following MIT invitational because of jerky motor performance. Connected between IMA7_VCC and GND on ICSP header on rear of board.

The pulley system, powered by the motor, lifts a mass up 10cm and hits two limit switches, one turns off the motor and the other triggers the next action.

"Use a Pulley system with an ideal mechanical advantage (IMA) of at least 7, that lifts an object that is at least 500 g at least 10 vertical cm before the object initiates the next action."



IMA 7 PULLEY ACTION


TITLE: WMHS MIT Invitational Circuit Board


Document Number:

REV:



Date: 1/21/2018 11:51 PM

Sheet: 13/16





Previous transfer triggers DFrobot sound recording module (connected to J6), which then plays the end recording.



END TASK

TITLE: WMHS MIT Invitational Circuit Board











Document Number:

REV:

Date: 1/21/2018 11:51 PM

Sheet: 15/16

"The device must play a recording of the phrase "The End" to signal the end of the run. This phrase must be clearly audible, and demonstrated for the judges prior to the run."



Power and Inter-Action

TITLE: WMHS MIT Invitational Circuit Board

Document Number:

REV:

Date: 1/21/2018 11:51 PM

Sheet: 16/16